



# ER-605

**PRODUCT TECHNICAL DATA SHEET**



## USAGE

Murakami 605 Emulsion Remover is a super concentrated emulsion remover with cleaning additives and degreasing agents. ER-605 can be used for all types of photopolymer and diazo emulsions and capillary films. Do not use ER-605 in automated reclaiming units where foaming could be a problem.

## ADVANTAGES:

- Concentrate: Dilute 1 part of ER-605 with 10 to 30 parts of water
- Safe on all types of mesh
- Will not crystallize, coagulate, or plug rinse jet nozzles on automatic reclaiming unit.
- Easily mixes with regular cold tap water
- Non-hazardous and drain safe. Always check with your local waste authority.

## APPLICATION:

### Step 1:

Remove all ink from the screen and wash with either SC-501, SC-505, or SC-507 screen cleaner depending on ink system used. Rinse both sides of screen with water.

### Step 2:

Spray or wipe ER-605 onto both sides of the screen. Allow 30 to 60 seconds to allow for full penetration.

### Step 3:

Remove emulsion residue from the screen with a high pressure water rinse.

**\*\* ALWAYS READ THE MSDS SHEET \*\***

IMPORTANT: Technical data herein is believed to be accurate. It is offered for your consideration, investigation, and verification. Buyer assumes all risk of use, storage, and handling of the product. No warranty, express or implied is made, including but not limited to, implied warranties of merchantability and fitness for a particular purpose. Nothing contained herein shall be considered as a license to operate under, or recommendation to infringe any patents.



**MURAKAMI**

**MURAKAMI SCREEN USA, INC.** 745 Monterey Pass Rd. Monterey Park, CA 91754

TEL: 323.980.0662, FAX: 323.980.0659 [www.murakamiscreeen.com](http://www.murakamiscreeen.com)

